

BERENDS

Rippers

Berends rippers enable you to do a lot of hard work with minimum effort.

Ideal for breaking up hard ground, ripping up stumps or rocks, planting trees, laying polythene pipe or removing rabbit warrens.

Compact Ripper

- * Designed to suit compact tractors (Cat 0 / Cat 1 linkage)
- * 100 x 25 billet
- * Reversible point 225mm x 75mm x 16mm
- * Weight: 40kg
- * Max working depth: 350mm

Heavy Duty Ripper

- * Designed for tractors over 60HP. (Cat 2 linkage)
- * 150 x 50 billet
- * Reversible point 225mm x 75mm x 16mm
- * Weight: 100kg
- * Max working depth: 700mm



Standard Ripper

- * Designed to suit 25-70 HP tractors (Cat 1 linkage with Cat 2 bushes)
- * 150 x 32 billet
- * Reversible point 225 x 75mm x 16mm
- * Weight: 72kg
- * Max working depth: 500mm



Pipelayer

- * Bolt on pipelayer easily removable
- * 80mm inside diameter takes 50mm polythene pipe
- * Suits single tine rippers only


Pictured: Standard ripper with pipelayer

Twin Ripper (left)

- * Designed to suit 60+ HP tractors depending on conditions (Cat 1 linkage with Cat 2 bushes)
- * Two 150 x 32 billets
- * Reversible points 225 x 75mm x 16mm
- * Weight: 110kg
- * Max working depth: 500mm

Mole Drainer (right)

- * Designed to create a "mole hole" to increase drainage in wet pastures
- * Adjustable depth dual cat linkage
- * 300 x 20mm tapered billet with 50mm tapered foot and floating 90mm "mole"



John Berends Implements Pty Ltd

130 Frankston-Dandenong Rd, Dandenong South, Vic. 3175

Ph: (03) 9791 2494 Fax: (03) 9794 5568

email: berends@johnberendsimplements.com.au

www.johnberendsimplements.com.au

